


MANUAL DE INSTRUÇÕES
USER'S MANUAL

VX9P



ONE

ON TIME STYLE



COMO AJUSTAR A HORA

- 1** Puxe a coroa para a primeira posição quando o ponteiro dos segundos estiver na posição das 12 horas
- 2** Gire a coroa para definir os ponteiros das horas e minutos
Gire a coroa para ajustar a hora levando AM / PM em consideração
- 3** Ponha a coroa de volta para a posição normal

COMO DEFINIR A DATA E O DIA DA SEMANA

- Correção do dia: Cada vez que pressiona o botão A, o ponteiro do dia avança para o próximo dia da semana
- Correção da data: Cada vez que pressiona o botão B, o ponteiro do dia avança 1 dia


Não acerte a data e os ponteiros do dia entre 21h00 e 4:00 am ..

Caso contrário, eles podem não mudar corretamente



ONE

ON TIME STYLE



HOW TO SET TIME

- 1** Pull the crown out to the 1st click position when the second hand is at the 12 o'clock position.
- 2** Turn the crown to set the hour and minute hands.
Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.
- 3** Push the crown back to the normal position.

HOW TO SET DATE AND DAY OF THE WEEK

- Day Correction : With each pressing of the button A, the day hand advances to the next day of the week
- Date Correction : With each pressing of the button B, the date hand advances 1 day.

Do not set the date and the day hands between 9:00 p.m. and 4:00 a.m..
Otherwise, they may not change properly.

onewatchcompany.com

ONE

ON TIME STYLE